



(A) CORNER




11 BEADS 4" O.C.
4" FROM ENDS

(B) PERIMETER




7 BEADS 6" O.C.
6" FROM ENDS

(C) FIELD




4 BEADS 12" O.C.
6" FROM ENDS


CORNER FASTENING



BUILDING HEIGHT
≤ 60 FEET



BUILDING HEIGHT
> 60 FEET



LOW RISE FOAM FASTENING ZONES & PATTERNS

Scale: N.T.S.

- NOTE:**
1. WHEN APPLYING MULTIPLE LAYERS OF INSULATION, IT IS REQUIRED TO RUN THE BEADS PERPENDICULAR TO THE PRECEEDING LAYER.
 2. IF A PORTION OF A BOARD EXTENDS INTO ANOTHER ZONE, IT MUST DEFER TO THE ZONE OF THE GREATER FASTENING PATTERN.



Notes: This detail is in accordance with the BRANZ Appraisal and CodeMark certification. Please contact us for any required customization.
© Ultraguard LTD

Technical Support and Advice:
Email: technical@gaf.nz
Call: 0800 42 33 55
Web: www.gafroofing.co.nz/TPO
GAF New Zealand Distributor

Drawing Title:
GAF EverGuard TPO Roofing

REF:
T-913

Date:
17/01/2025

Version:
A