


TPO COVER TAPE HEAT WELD STRIP OVERLAP AT ROOF EDGE

Scale: N.T.S.



NOTES:

1. CLEAN METAL AND MEMBRANE WITH EVERGUARD® TPO SEAM CLEANER OR EVERGUARD® CLEANWELD™ CONDITIONER AND ALLOW TO DRY.
2. PRIME TOP OF FLASHING WITH TPO PRIMER OR LOW VOC TPO PRIMER.
3. DO NOT SPILL PRIMER ON HEAT WELDED SEAM AREA.
4. DO NOT OVERLAP ENDS OF FLASHING WITH FLASHING STRIP.
5. HEAT WELD THE COVER TAPE (NON-ADHESIVE SIDE ONLY) TO THE MEMBRANE AREA USING A 1-1/2" [38.1 mm] WELD WITH MACHINE AUTOMATIC WELDER.
6. CONTACT GAF FOR APPROPRIATE RECOMMENDATIONS NEEDED FOR ANSI/SPRI/FM4435/ES-1 DESIGN CRITERIA.



Notes: This detail is in accordance with the BRANZ Appraisal and CodeMark certification. Please contact us for any required customization. © Ultraguard LTD

Technical Support and Advice:
Email: technical@gaf.nz
Call: 0800 42 33 55
Web: www.gafroofing.co.nz/TPO
GAF New Zealand Distributor

Drawing Title: GAF EverGuard TPO Roofing		
REF: T-918	Date: 17/01/2025	Version: A