



## UNIVERSAL PREFORMED CORNER

Scale: N.T.S.

### NOTES:

1. FLASHING MAY BE ADHERED OR INSTALLED DRY (REFER TO 300 DETAIL SERIES).
2. KEEP FASTENERS BACK FROM CORNER 152 mm MAXIMUM.